



**1853544**

## **Tulip Hall Table**

### **Parts and Hardware List**


A.	Wood Top	1 pc
B.	Metal Frame	1 pc
C.	Wood Base	1 pc
D.	Flat Washers	8 pcs
E.	Lock Washers	8 pcs
F.	Allen Head Bolts	4 pcs
G.	Allen Head Wrench	1 pc
H.	Hexagon Nuts	4 pcs
I.	Open End Wrench	1 pc

\* Please make sure that you have all the parts and hardware indicated above before you begin assembly of this item.


\* This item should be assembled on a soft surface to prevent scratching of the finish during assembly.

\* This item may require periodic tightening.


### **Hardware Illustrations**




**F. Allen Head Bolt**



**D. Flat Washer**



**H. Hexagon Nut**



**E. Lock Washer**



**1853544**

## **Tulip Hall Table**

### **Attach Wood Top and Base to Metal Frame**

#### **Parts required**

A.	Wood Top	1 pc	F.	Allen Head Bolts	4 pcs
B.	Metal Frame	1 pc	G.	Allen Head Wrench	1 pc
C.	Wood Base	1 pc	H.	Hexagon Nuts	4 pcs
D.	Flat Washers	8 pcs	I.	Open End Wrench	1 pc
E.	Lock Washers	8 pcs			

1. **Attach Wood Top (A)** Place the Wood Top (A) upside down on a soft surface. Align the pre-drilled holes of the Metal Frame (B) with the pre-threaded holes on the Wood Top (A), secure with Allen Head Bolts (F), Lock Washers (E) and Flat Washers (D) using Allen Head Wrench (G). See Illustration.
2. **Attach Wood Base (C)** Align the pre-drilled holes on the Wood Base (C) with the exposed threads of the Metal Frame (B), Secure with Hexagon Nuts (H), Lock Washers (E) and Flat Washers (D) using Open End Wrench (I). See Illustration.

